

CANON INK**DESCRIPTION**

BCI3E BLACK
 BCI 3E C /Y/ M
 BCI 6 BLACK
 BCI 6 C/ Y/ M
 CLI 8 BLACK
 CLI 8 GREEN/ RED
 BCI 15 BLACK TWIN
 BCI 16 COLOUR TWIN
 BCI 16 COLOR
 BCI 24 COLOR
 BCI 24 BLACK
 PG210 BLACK
 CL211 COLOR
 PG510 BLACK
 CL 511 COLOR
 CLI521 BLACK
 CLI521 C/ Y/ M
 CLI 221 BLACK
 CLI221 C/ Y/ M
 PG37 BLACK
 CL 38 COLOR
 PG40 BLACK
 CL41 COLOR
 PGI5BK BLACK
 PGI520 BLACK
 CLI246 BLACK C/Y/ M
 PGI425 BLACK

CANON TONERS

EP 307/707 BLACK
 EP 307/707 C/Y/M
 EP308/708 BLACK
 EP22 BLACK
 EP25 BLACK
 EP26/27 BLACK
 CARTRIDGE T
 FX-3 BLACK
 FX-7 BLACK
 FX-10 BALCK
 EP301/701 BLACK
 EP301/701 C/Y/M
 EP303/703 BLACK
 EP 328/728 BLACK
 EP325/725 BLACK
 EP723/323 BLACK
 EP723/323 C/Y/M
 EP 719/319 BLACK
 EP318/718 BLACK
 EP318/718 C/Y/M
 EP712/312 BLACK

LEXMARK INK**DESCRIPTION**

INK COLOR10N0227
 INK BLACK 10N0217
 INK BLACK 10N0016
 INK COLOR 10N0026
 INK BLACK 13400HC
 INK BLACK 12A1970
 INK COLOR 12A1980
 INK COLOR 17G0050
 INK CART NO.34 MONO 18c0034
 INK CART NO.35 COLOUR 18C0035
 INK CART NO.28 RET PROG MONO 18C1428
 INK CART NO.29 RET PROG COLOUR 18C1429
 INK CART NO.23 RET PROG MONO 18C1523
 INK CART NO.24 RET PROG COLOUR 18C1524
 INK CART NO.14 RP MONO 18C2090
 INK CART NO.15 RP COLOUR 18C2110
 MONO PRINT CART. 36 EMEA 18C 2130
 COLOR PRINT CART. 37 EMEA 18C2140
 INK CART NO.82 MONO 19L0032
 INK CART NO.44 MONO 18Y0144
 INK14N0820E BLACK #100
 15N0900E/901/902 C/Y/M #100
 15M0120 COLOR # 20
 18C0781 COLOR #1
 18C0032 BLACK #32
 18C0033 COLOR #33
 18L0042 COLOR #83
 18Y0143 COLOR #43

LEXMARK RIBBON

11A3540 Ribbon

LEXMARK TONER

08A0476 (E 320/22)
 10S0063 (E 210)
 12017SR (E120N)
 12A6860 (T620/22)
 12A7400 (E321/23)
 12A7405 (E321/23)
 12A7415 (T420d)
 12A7460 (E630/32/34)
 12A8302 (E230/234)
 12A8400 (E330/32)
 12A8420 (T430)
 12S0400 (E220)
 18S0090 (X215)
 24016SE Blk (E232/240/330)
 24017SR (E232/240)
 64016HE Blk (T640/642/644)
 64016SE (T640/T642/T644)
 64017HR (T640/T642/T644)
 64017SR (T 640)
 T650A11E Blk (T650/652/654)
 C5220KS Black (C522)
 C5220CS Cyan (C522)
 C5220MS Magenta (C522)
 C5220YS Yellow (C522)
 C540A1K Blk (C540/X543)
 C540A1C Cy (C540/X543)
 C540A1M Mag (C540/X543)
 C540A1Y (C540/X543)
 C540H1KG Blk (C540/C543)
 C540H1CG Cy (C540/C543)
 C540H1MG Mag (C540/C543)
 C540H1YG Yel (C540/C543)
 C780A1KG Blk (C780/782)
 C780A1CG Cy (C780/782)
 C780A1MG Mag (C780/782)

BROTHER INK & TONER**DESCRIPTION**

LC39 BLACK
 LC39 CYAN YELLOW MAGANTA
 LC38 BLACK
 LC38 CYAN YELLOW MAGANTA
 LC67 BLACK
 LC 67 CYAN YEL00W MAGANTA
 TN2150 TONER
 TN 2130 TONER
 LC37 BLACK
 LC37 CYAN YELLOW MAGANTA
 TN240 BLACK TONER
 TN240 CYAN YELLOW MAGANTA
 TN150 BLACK TONER
 TN150 CYAN YELLOW MAGANTA
 DR 2125 DRUM
 DR240 DRUM
 DR150 DRUM
 LC 57 BLACK
 LC57 CYAN YELLOW MAGANTA

EPSON RIBBON**DESCRIPTION**

EPSON RIBBON FOR LQ300 7753
 EPSON RIBBON FOR LQ680
 EPSON RIBBON FOR LQ1170 7754
 EPSON RIBBON FOR LQ2180 2070 S020186
 EPSON RIBBON FOR LQ2090
 EPSON RIBBON FOR LQ690
 EPSON RIBBON FOR ERC37 38
 EPSON RIBBON FOR ERC9

C780A1YG Yel (C780/782)
E250X22G (E25X/35X/45X)
E250A11P Black (E250)
E250A11E Blk (E250DN/350D)
E260A11E Blk (E260/E360/E460)
E260A11P Blk (E260/E360/E460)
E450A11P (E450dn)